

Shoot Smarter.

INSTALLATION INSTRUCTIONS:

Use a compatible screwdriver for the removal of your stock recoil pad and fitting of your SmartCells Advanced Recoil Pad. Lubricate the screwdriver with your lube of choice (rubber grease, WD-40, or other rubber suitable lubrication). Don't attempt to sand or grind down the SmartCells Recoil Pad. It is engineered to this specific size and form for maximum recoil reduction. Altering the product directly effects performance and void's the manufacturing warranty.

STEP 1: Remove your existing recoil pad using a compatible screwdriver.

STEP 2: Test fit your SmartCells recoil pad by placing it on the stock and lining it up with the perimeter. Ensure that the through holes in the pad align with the mounting holes in your rifle stock.*

STEP 3: Attach the SmartCells recoil pad using pan head screws of appropriate length.

STEP 4: Apply lubrication to the screw and screwdriver, push the screw through the rubber holes on the SmartCells recoil pad so they extend through the holes in the mounting plate.

STEP 5: Tighten the screws into the stock of the rifle.

STEP 6: Wipe/clean away any excess lubricant off of your SmartCells Recoil Pad.

STEP 7: Start picking your mark and bringing home some trophies.

*In the case the mounting holes do not line up or the existing recoil pad is not fitted by screws we recommend the installation be completed by a qualified gunsmith.